

This document provides clear instructions for installing a decorative dormer on a cabin roof. The dormer consists of three triangular pieces (one front, two sides) plus apex fascia trim.

Key points from the instructions:

Preparation considerations:

- » The dormer follows standard dimensions, so you may need to adjust it to match your specific roof angle using a saw, pencil, and ruler
- » While there are suggested placement drawings, you can position it anywhere since it's purely decorative and doesn't affect structural integrity
- » The apex fascia comes slightly longer than needed and will require trimming

Installation process:

- » Secure the dormer to the roof logs using nails or screws
- » The diagram shows attachment points along the dormer's base and sides
- » Use additional fasteners as needed for stability
- » Make sure to fix it from both sides for proper support

The visual shows the dormer mounted on a shingled roof with red arrows indicating the primary attachment points. The saw illustration emphasizes that cutting/adjusting may be necessary during installation.



Screw or nail
the Dormer here

Use some more nails
or screws if needed.

Fix it from both sides

