

Now, when everything is done it is time for the final cosmetic part.

Tools that will be useful or necessary

Tools



Skirting board.

Skirting boards are used to cover the gap between the floor planks and the wall. All skirting boards are about 100mm longer than a distance between the cabin walls. So, you will have to do some work by hand, but be careful, don't cut too much. Study the Floor Plan carefully, pick and mark all the parts of a skirting board, so you would know exactly where each of it goes.

Diamond Shape

It is the very last part, which rises on top of the roof's triangle and grants the cabin its unique charm. It is fixed on top of the roof triangle and covers the connection of Apex Fascia.

